



# SCHEMATICS

CUSTOMER SERVICE  
**1-800-446-1071**


Export (General) / Gas / Gas Go-Anywhere

[EMAIL](#) | [CLOSE](#)

MODEL #: 1141079 DESCRIPTION: GAS GO-ANYWHERE, BLACK, GERMANY/AUSTRIA (2014)

[Print Schematic](#)

Gas Go Anywhere  
Additional Parts



08.13

Seq#	Part #	Description
	58201	Assembly guide, Gas-Go-Anywhere, 30/37/50mb, EU '14
	58205	Owner's Guide, Gas-Go-Anywhere, 50mb, EU '14
	85113	Charcoal warranty addendum, Germany/Austria '14
	48607	Owner's Guide, Gas Go-Anywhere, Germany/Austria '15
	65094	Hardware, Bowl, Gas-Go-Anywhere, '14 EU

	80215	Hardware pack for Go-Anywhere gas grill
	80211	Hardware for the Charcoal Go-Anywhere Grill.
1	80672	Handle kit w/shield, '15
2	69977	Lid assembly, Gas-Go-anywhere, black, export '14
3	69978	Porcelain enameled cooking grate, Gas-Go-Anywhere '14
4	69976	Burner tube assembly, Gas-Go-Anywhere, export '14
5	69966	Heat shield, Gas-Go-Anywhere, export '14
6	69972	Valve/regulator assembly, 50mb, Gas-Go-Anywhee, export '14
7	69986	Control knob, Gas-Go-Anywhere, export '14
8	69975	Control panel cover, Gas-Go-Anywhere, black, export '14
9	69973	Igniter kit, Gas-Go-Anywhere, export '14
10	69974	Control panel, Gas-Go-Anywhere, export '14
11	69965	Bowl, Gas-Go-Anywhere, black, export '14
11	65094	Hardware, Bowl, Gas-Go-Anywhere, '14 EU
12	65063	Wire legs w/hardware, Gas Go-Anywhere '14 - export
13	80211	Hardware for the Charcoal Go-Anywhere Grill.